

Scratch removal	Step 2  POLAROS® RP 600 polisher Polarshine® 20 compound Golden Finish pad 1
Hologram removal	Step 3  POLAROS® RP 600 polisher Polarshine® 5 compound Golden Finish pad 2
Finish	Step 4  Cleaning Cloth Micro Fiber Yellow

FRESH CLEARCOAT PROCESS



STEP 1 – Cleaning

Wash or clean the surface to avoid any contamination. Use e.g. IPA or a silicon remover.



STEP 4 – Finish

Wipe the surface clean with a micro fiber cloth.



STEP 2 – Scratch removal

Polish the surface with POLAROS RP 600. Set the speed to 1000–1300 rpm. Use Polarshine 20 and Golden Finish pad 1.



STEP 3 – Hologram removal

Continue polishing with POLAROS RP 600, and same speed 1000–1300 rpm. Use Polarshine 5 and a Golden Finish pad 2.



POLAROS® RP 600 – High performance, lightweight rotary polisher.

Power: 750W, speed: 700–2500 rpm, size of backing pad: 135 diameter, weight: 1.7 kg and sound power level: 65.5 dB(A).