





# SET UP INSTRUCTIONS




1. Stand the frame upright and pull legs outward




2. Place the canopy on the frame and attach it to the poles using the velcro straps



3. Lift the slider on the legs until you hear a click



4. Press and hold buttons on legs to adjust the tent height



5. Use the ropes and stakes to secure the canopy to the ground