


GASKET INSTALLATION - STEP 1



1) As pictured, engage slot at the bottom of the lens gasket into the tab at the bottom of the hybrid frame.

GASKET INSTALLATION - STEP 2



2) Rotate the gasket up to engage the corresponding slot and tab at the top of the hybrid.

MAINTENANCE: Wiley X lenses are specially coated to offer superior abrasion resistance. Please follow below instructions to prolong the life of your lenses and keep them performing at their best:

- Clean lenses with water only.
- Do not use solvents or special cleaners.
- Use micro-fiber cleaning cloth provided to gently wipe clean.
- Never use paper products to clean and avoid wiping lens surface when dry and/or dirty as this may potentially scratch the lens.

WARNING: Wiley X brand eyewear is tested tough. However, impact resistant eyewear is not unbreakable and does not provide unlimited eye protection under all circumstances and conditions. Misused, abused, scratched and/or damaged eyewear can reduce impact protection (and void your limited warranty). Dirty and/or wet eyewear can impair vision and reduce safety (resulting in personal injury and/or property damage). Keep your Wiley X eyewear clean with water only. Do not use solvents or abrasives as it could scratch or damage the product reducing its effectiveness. Store your Wiley X eyewear in the protective case provided to prolong the life of the lenses. Most of all, take all appropriate precautions when wearing your Wiley X eyewear during hazardous and/or dangerous activities and conditions. Wiley X, Inc. is not responsible for personal injury, property damage or losses incurred while using Wiley X brand products.



WILEY X INC. 1.800.776.7842 // 925.243.9810 // WILEYX.COM
7800 PATTERSON PASS ROAD, LIVERMORE CA 94550 USA
WILEY X EUROPE LLC: +45 96 93 00 45 // WILEYX.EU
SØNDERGADE 8-10 7570 VEMB DENMARK ERX-ICSG1[1]




SG-1 INSTRUCTIONS

COPYRIGHT © 2016 WILEY X, INC. ALL RIGHTS RESERVED.


WILEY X, WX, BLACK OPS, logos, tag lines and product names are trademarks or registered trademarks (marcas registradas) of Wiley X, Inc. in the U.S. and other countries. Logos © 2007-2016 Wiley X, Inc. All rights reserved.

LENS REMOVAL




Hold the product as pictured.

LENS REMOVAL




Lift the frame at the nose bridge while pushing down on the lens to create about 1/4 inch separation between the lens and frame.

LENS REMOVAL



Hold the frame at the nose piece and rotate the lens from top of the frame.

TEMPLE / STRAP REMOVAL



Press the tab located in the graphic above to release either the temples or strap.