



## LENS REMOVAL



To separate the lens from the frame grasp the brow bar indicated in the drawing and pull apart.

## NOSE PIECE REMOVAL\*

1) The nose piece and primary lens are interlocking.




2) To detach pull a leg of the nose piece. Once the leg is disengaged the nose piece will simply rotate out.




\*Should you require corrective lenses remove the rx carrier prior to removing the nosepiece. See Rx Carrier instruction

## INSTALLING THE LENS - STEP 1




Position the slot of the brow bar to the notch of the lens...

## INSTALLING THE LENS - STEP 2




... and squeeze together as pictured

## INSTALLING NOSE PIECE




To install the nose piece, simply align the slot of the nosepiece with the lens and squeeze together.

## NOSE PADS ADJUSTMENT




The wire core nose pads are adjustable ensuring the best fit for you.

## INSTALLING THE PRESCRIPTION CARRIER - STEP 1




The prescription carrier is held in place by aligning the buds on the Rx carrier into the notches on the nose piece.

## INSTALLING THE PRESCRIPTION CARRIER - STEP 2




Align the groove of the nose piece into the center notch of the frame.

## INSTALLING THE PRESCRIPTION CARRIER - STEP 3



Position hands as pictured above and squeeze together until the nose piece completely seats into the lens.

## TEMPLES / TACTICAL STRAP



### TEMPLE ADJUSTMENT

The length of the temple arm may be adjusted by up to .75" with the 4 position extendable arm.

### INSTALLING TACTICAL STRAP

Pull the adjustable temple arm so it is separated from the frame. Replace with tactical strap connectors, pushing firmly until they click.