




48PM21  
GW 48V 21" Brushless Mower (Kitted)  
2527002



48PM21  
GW 48V 21" Brushless Mower (Kitted)  
2527002



48PM21  
GW 48V 21" Brushless Mower (Kitted)  
2527002



48PM21

GW 48V 21" Brushless Mower (Kitted)

2527002

Deck And Wheels

Item #	Part Number	Description
1	R0200071-00	Height Adjust Handle Kit
2	RB333031560	Deck Bracket Assembly (Right)
3	RB341271179A	Rear Wheel Kit
4	RB311011179	Rear Axle Kit
5	RB311201546	Side Discharge Cover Assembly
6	R0200079-00	Deck Bracket Assembly (Left)
7	RB333011546	Height Adjust Rod Assembly
8	R0200080-00	Deck
9	RB341281179A	Front Wheel Kit
10	RB311021179	Front Axle Kit

Handles and Controls

1	R0200059-00	Main Bail
2	R0200077-00	Upper Handle Assembly
3	R0200872-00	Power head and Switch Assembly
4	RB341291179A	Handle Connection Kit
5	RB333121179A	Lower Handle Kit
6	RB333041179	Blade
7	RB341191179V1	Blade Fan Kit
8	R0200075-00	Key

Housings

1	R0200076-00	Front Bumper Kit
2	R0200072-00	Front Skirt Kit
3	RB341241179C	Side Discharge Chute
4	RB341251179A	Rear Discharge Cover Kit
5	RB341011179B	Back Skirt Assembly
6	R0200078-00	Rear Discharge Plug
7	R0200069-00	Bag Kit
8	RB342011179	Rear Grass Flap