


GS 110  
40V 10" Top Handle Chainsaw (1) 3AH  
2004902



GS 110  
40V 10" Top Handle Chainsaw (1) 3AH  
2004902

Item #	Part Number	Description
1	RB34114155C	Scabbard
2	RB322001726C	Bar
3	RB311101726	Chain
4	R0200016-00	Scrench
5	RB311021898	Oil Cap Assembly
6	R0200863-00	Bar Nuts
7	RB311041898A	Bar Cover Assembly
8	RB311031063AA	Tensioner Kit
9	RB333061075AA	Chain Catcher
10	RB339001726A	Drive Gear Kit