


GREENWORKS

COMMERCIAL

Zero Turn Mower
7404902 (Model No.CZ52S)
7404802 (Model No.CZ48S)



Parts Manual

TOLL-FREE HELPLINE: 1-855-470-4267

www.GreenworksCommercial.com

 Read all safety rules and instructions carefully before operating this tool.

CONTENTS

Labels

LABELS-WARNING/SAFETY.....	15
LABELS-BRAND/MODEL.....	16
LABELS-FUNCTION.....	17

Body and structures

FRAME.....	21
BATTERY COVER.....	22
TOWER.....	23
LOWER PANEL.....	24
FENDERS.....	28

Electrical System

BATTERY AND CHARGER.....	31
CONTROLLERS AND BOX.....	32
WIRE HARNESS.....	33
SWITCHES.....	35
GPS.....	36
LIGHTS.....	39

Deck System

DECK ASM, MOTORS, BLADES.....	41
DECK COMPONENTS.....	42
DECKLIFT.....	45
DECKLIFT FRONT ROTATING SHAFT ASSEMBLY.....	46
DECKLIFT REAR ROTATING SHAFT ASSEMBLY.....	47

Drive System


WHEELS.....	51
FRONT CASTER PARTS.....	52
DRIVE MOTOR AND TRANSMISSION.....	55

Operator System


SEAT.....	61
CONTROL ARMS.....	63
RH CONTROL ARM SUB STRUCTURE.....	64
LH CONTROL ARM SUB STRUCTURE.....	65

NOTE: ILLUSTRATIONS MAY OR MAY NOT REPRESENT THE ACTUAL ASSEMBLIES AND IT IS NOT RECOMMENDED TO USE THIS MANUAL AS A GUIDE TO ASSEMBLE OR DISASSEMBLE THE MOWER.


LABELS-WARNING/SAFETY



15-01 (for 7404802)



15-01 (for 7404902)



15-02



15-03





15-04



15-05

ITEM NO.	PART NO.	DESCRIPTION	QTY
15-01	R0202948-00 (For 7404802)	48in Safety Label	1
	R0202950-00 (For 7404902)	52in Safety Label	1
15-02	R0201623-00	Warning label	1
15-03	R0202922-00	No standing label	2
15-04	R0201625-00	CP65 label	1
15-05	R0201627-00	Keep H/F away	1



LABELS-BRAND/MODEL



16-01



16-02



16-03

CZ 48s

16-04 (for 7404802)

48"

16-05 (for 7404802)


CZ 52s

16-04 (for 7404902)


52"

16-05 (for 7404902)


ITEM NO.	PART NO.	DESCRIPTION	QTY
16-01	R0202920-00	82V li-ion max label	1
16-02	R0202916-00	Greenworks COMMERCIAL label	1
16-03	R0202944-00	G+ETO logo label	1
16-04	R0202947-00 (For 7404802)	48in model label	1
	R0202949-00 (For 7404902)	52in model label	1
16-05	R0202938-00 (For 7404802)	48in deck size label	1
	R0202918-00 (For 7404902)	52in deck size label	1




LABELS-FUNCTION




17-01



17-02




17-03




17-04

ITEM NO.	PART NO.	DESCRIPTION	QTY
17-01	R0202946-00	Control panel label	1
17-02	R0202941-00	Parking L label	1
17-03	R0202942-00	Parking R label	1
17-04	R0202945-00	Cutting height adjustment label	1




FRAME




ITEM NO.	PART NO.	DESCRIPTION	QTY
21-01	R0201377-00	Front fender welment	1
21-02	R0200532-00	Bolt assembly	4
21-03	R0201813-00	Chassis weldment	1
21-04	R0200466-00	Bottom plate	1
21-05	R0200534-00	Bolt assembly	8
21-06	R0200391-00	Seal	2
21-07	R0200349-00	Bolt M8×35	2
21-08	R0200348-00	Spring washer	2
21-09	R0200695-00	Spring	2
21-10	R0200548-00	Washer	8
21-11	R0200520-00	Lock nut M8	10
21-12	R0200552-00	Handle ball type A M10×20	1
21-13	R0200553-00	Nut M10	1
21-14	R0200608-00	Spring	1
21-15	R0200505-00	Bolt M12×100	2
21-16	R0200691-00	Roller shaft	2
21-17	R0200363-00	Roller Wheel	2
21-18	R0200692-00	Spacer	2
21-19	R0200609-00	Pin latch	1
21-20	R0200710-00	Rubber bumper	2
21-21	R0200398-00	Bolt M8×25	4
21-22	R0200541-00	Large washer	6
21-23	R0200697-00	Spring	2
21-24	R0200549-00	Nut M8	2
21-25	R0200684-00	Grease zerk fitting M6	2
21-26	R0200619-00	Rubber strip	0.57 M
21-27	R0200619-00	Rubber strip	0.28 M
21-28	R0200619-00	Rubber strip	0.28 M
21-29	R0200619-00	Rubber strip	0.56 M
21-30	R0200673-00	Compression spring assembly	1
21-31	R0200526-00	Bolt M8×20	2
21-32	R0200441-00	Spring plate	1
21-33	R0200347-00	Spring	2

BATTERY COVER




ITEM NO.	PART NO.	DESCRIPTION	QTY
22-01	R0200480-00	Cover assembly , Battery	1
22-02	R0200613-00	Cover, Battery	1
22-03	R0200612-00	Handle	1
22-04	R0200538-00	Spring washer	2
22-05	R0200545-00	Washer	2
22-06	R0200555-00	Screw M5×10	2
22-07	R0200399-00	Rotary tongue lock	1
22-08	R0200439-00	Left side plate	1
22-09	R0200534-00	Bolt assembly	12
22-10	R0200520-00	Lock nut M8	2
22-11	R0200518-00	Lock nut M6	2
22-12	R0200400-00	Gas shock	1
22-13	R0200507-00	Bolt M6×20	2
22-14	R0200597-00	Bushing	2
22-15	R0200549-00	Nut M8	4
22-16	R0200450-00	Front plate	1
22-17	R0200453-00	Right side plate	1
22-18	R0200619-00	Rubber strip	0.61 M
22-19	R0200620-00	Thin bumper strip	0.2 M
22-20	R0200621-00	Rubber strip	1.8 M

TOWER




ITEM NO.	PART NO.	DESCRIPTION	QTY
23-01	R0201814-00	Control tower weldment	1
23-02	R0200413-00	Control stop weldment	1
23-03	R0200498-00	Bolt M8×45	2
23-04	R0200513-00	Nut M8	2
23-05	R0200534-00	Bolt assembly	14
23-06	R0201100-00	Tower front plate	1
23-07	R0200549-00	Nut M8	2
23-08	R0200414-00	Guide control arm	2
23-09	R0200565-00	Screw ST4.2×10	6
23-10	R0201099-00	Console plate	2
23-11	R0200526-00	Bolt M8×20	4
23-12	R0200496-00	Lock nut M8	4
23-13	R0202965-00	Control lever assembly	1

LOWER PANEL




ITEM NO.	PART NO.	DESCRIPTION	QTY
24-01	R0200683-00	Cushion (lower)	1
24-02	R0200463-00	Rear plate	1
24-03	R0200534-00	Bolt assembly	10
24-04	R0200548-00	Washer	2
24-05	R0200520-00	Lock nut M8	2
24-06	R0200527-00	Bolt M8×25	2
24-07	R0200549-00	Nut M8	2
24-08	R0200391-00	Plug	2
24-09	R0200576-00	Rear cover	1

FENDERS




ITEM NO.	PART NO.	DESCRIPTION	QTY
28-01	R0200521-00	Lock nut	2
28-02	R0200506-00	Bolt M10X25	4
28-03	R0200527-00	Bolt M8×25	2
28-04	R0200314-00	Screw M8	2
28-05	R0201413-00	Right fender	1
28-06	R0201416-00	Left fender	1

BATTERY AND CHARGER




ITEM NO.	PART NO.	DESCRIPTION	QTY
31-01	R0200518-00	Lock nut M6	4
31-02	R0200547-00	Washer	4
31-03	R0200729-00	Charger plug	1
31-04	R0200570-00	Screw M6×25	4
31-05	R0201161-00	Lithium battery 16 kWh	1
31-06	R0201227-00	Charger 120V/15A - 240V/22A, 2100 Watt	1
31-07	R0201436-00	Charger socket	1
31-08	R0202724-00	Adapter 240/120V	1

CONTROLLERS AND BOX




ITEM NO.	PART NO.	DESCRIPTION	QTY
32-01	R0200528-00	Bolt M8×30	4
32-02	R0200392-00	Bushing	8
32-03	R0200393-00	Washer	8
32-04	R0200520-00	Lock nut M8	4
32-05	R0202863-00 (For 7404902)	Drive controller assembly	1
	R0202864-00 (For 7404802)		1
32-06	R0200716-00	Blade controller assembly	1

WIRE HARNESS




ITEM NO.	PART NO.	DESCRIPTION	QTY
33-01	R0201420-00	Wiring harness assembly	1
33-02	R0200723-00	Blade controller cable positive	2
33-03	R0200724-00	Blade controller cable negative	2
33-04	R0200725-00	Machine power harness	1
33-05	R0200726-00	Drive controller cable positive	1
33-06	R0200727-00	Drive controller cable negative	1
33-07	R0201430-00	Machine harness assembly	1
33-08	R0200428-00	Thermal silica film	1
33-09	R0200429-00	Guard ring	3
33-10	R0200511-00	Nut M5	2
33-11	R0200538-00	Spring washer	2
33-12	R0200545-00	Washer	2
33-13	R0200556-00	Screw M5×35	2
33-14	R0200390-00	Zip tie	50
33-15	R0201434-00	Attachment power cord	1
33-16	R0201435-00	Attachment socket	1
33-17	R0201288-00	Attachment Contactor	1
33-18	R0201437-00	Buzzer	1
33-19	R0200534-00	Bolt assembly	2
33-20	R0201287-00	Screw M5×14	4
33-21	R0200517-00	Lock nut M5	4
33-22	R0201328-00	Mounting plate	1
33-23	R0201715-00	Charger contactor	1
33-24	R0201433-00	Relay	1
33-25	R0200847-00	Fuse, 20A (regular)	1

SWITCHES




ITEM NO.	PART NO.	DESCRIPTION	QTY
35-01	R0201337-00	Attachment ON/OFF switch	1
35-02	R0202103-00	Key	1
35-03	R0202101-00	LCD Display	1
35-04	R0200717-00	PTO switch	1
35-05	R0200721-00	Blade speed switch	1
35-06	R0202102-00	Ignition switch	1
35-07	R0200719-00	Drive speed switch	1
35-08	R0200366-00	Parking switch	1
35-09	R0202104-00	Ignition switch with key	1

GPS




ITEM NO.	PART NO.	DESCRIPTION	QTY
36-01	R0201376-00	Screw	4
36-02	R0202868-00	GPS	1
36-03	R0201379-00	Nut	4

LIGHTS




ITEM NO.	PART NO.	DESCRIPTION	QTY
39-01	R0200551-00	Bolt M5×16	2
39-02	R0200545-00	Washer	2
39-03	R0200538-00	Spring washer	2
39-04	R0200511-00	Nut M5	2
39-05	R0200668-00	Light LED	1

DECK ASM, MOTORS, BLADES




ITEM NO.	PART NO.	DESCRIPTION	QTY
41-01	R0200408-00	Bolt M16×60	2
41-02	R0200409-00	Lock nut M16	2
41-03	R0200710-00	Rubber bumper	2
41-04	R0200496-00	Lock nut M8	2
41-05	R0201974-00 (for 7404902)	Deck Housing 52 inch	1
	R0201386-00 (for 7404802)	Deck Housing 48 inch	1
41-06	R0200359-00	Bolt M12×120	3
41-07	R0200691-00	Roller shaft	3
41-08	R0200363-00	Roller wheels	3
41-09	R0200692-00	Roller spacer	3
41-10	R0200523-00	Lock nut M12	3
41-11	R0200339-00	Washer	9
41-12	R0200350-00 (for 7404902)	18" Blade	3
	R0200705-00 (for 7404802)	16.25" Blade	3
41-13	R0200365-00	Blade washer	3
41-14	R0200364-00	Bolt M16×70	3
41-15	R0201314-00	Nut M8	3
41-16	R0200693-00	Blade collar	3
41-17	R0200502-00	Washer	18
41-18	R0200499-00	Spring washer	18
41-19	R0200501-00	Bolt M10×25	18
41-20	R0200714-00	Blade motor	3
41-21	R0200412-00	Hose clamp	3
41-22	R0200507-00	Bolt M6×20	3
41-23	R0201718-00 (for 7404902)	Motor assembly	3
	R0201811-00 (for 7404802)		3

DECK COMPONENTS




ITEM NO.	PART NO.	DESCRIPTION	QTY
42-01	R0200484-00 (for 7404902)	Grass cover assembly	1
	R0200764-00 (for 7404802)		1
42-02	R0200528-00	Bolt M8×30	5
42-03	R0200462-00 (for 7404902)	Lower bracket deflector	1
	R0201440-00 (for 7404802)		1
42-04	R0200618-00 (for 7404902)	Deflector rubber	1
	R0201306-00 (for 7404802)		1
42-05	R0200520-00	Lock nut M8	7
42-06	R0200541-00	Large washer	5
42-07	R0200575-00 (for 7404902)	Upper bracket deflector	1
	R0201441-00 (for 7404802)		1
42-08	R0200557-00	Lock nut M10	1
42-09	R0201286-00 (for 7404902)	52in Header weldment	1
	R0201380-00 (for 7404802)	48in Header weldment	1
42-10	R0201308-00 (for 7404902)	Connecting rod	1
	R0201382-00 (for 7404802)		1
42-11	R0200398-00	Bolt M8×25	2
42-12	R0200591-00	Connection pin weldment	2
42-13	R0200674-00	Tie rod assembly	2
42-14	R0200407-00	Rod end M16	2
42-15	R0200406-00	Nut M16	2
42-16	R0200577-00	Tie rod weldment	2
42-17	R0200684-00	Grease zerck fitting M6	2
42-18	R0200526-00	Bolt M8×20	2
42-19	R0200460-00 (for 7404902)	Air plate 1	1
	R0201324-00 (for 7404802)		1
42-20	R0200558-00	Lock nut M8	2
42-21	R0201383-00	Spring	1

DECKLIFT




ITEM NO.	PART NO.	DESCRIPTION	QTY
45-01	R0202013-00	Front height adjustment	1
45-02	R0200408-00	Bolt M16×60	2
45-03	R0200344-00 (for 7404902)	Connecting rod	1
	R0201442-00 (for 7404802)		1
45-04	R0200407-00	Rod end M16	1
45-05	R0200406-00	Nut M16	1
45-06	R0200421-00 (for 7404902)	Rod	1
	R0201326-00 (for 7404802)		1
45-07	R0200422-00	Nut M16	1
45-08	R0200423-00	Rod end M16	1
45-09	R0200409-00	Lock nut M16	2
45-10	R0200503-00	Washer	4
45-11	R0200701-00	Spacer	4
45-12	R0200521-00	Lock nut M10	12
45-13	R0200525-00	Collar	8
45-14	R0200737-00	Collar	4
45-15	R0200586-00	Shaft mount	4
45-16	R0201388-00	Rear height adjustment	1
45-17	R0201389-00	Height adjustment weldment	1
45-18	R0200424-00	Spring pin	1
45-19	R0200425-00 (for 7404902)	Spring	1
	R0201327-00 (for 7404802)		1
45-20	R0200508-00	Bolt M8×55	2
45-21	R0200590-00	Bushing	4
45-22	R0200548-00	Washer	4
45-23	R0200520-00	Lock nut M8	4
45-24	R0200510-00	Screw M8×65	2
45-25	R0201390-00	Pull rode welding	1
45-26	R0200487-00	Pin and leash	1

DECKLIFT FRONT ROTATING SHAFT ASSEMBLY




ITEM NO.	PART NO.	DESCRIPTION	QTY
46-01	R0202014-00	Front height weldment	1
46-02	R0200496-00	Lock nut M8	4
46-03	R0200706-00	Inner mounting plate	2
46-04	R0200515-00	Lock nut M12	2
46-05	R0200559-00	Nut M12	2
46-06	R0200700-00	Collor	2
46-07	R0200699-00	Trunion	2
46-08	R0201392-00	Eyebolt	2
46-09	R0200707-00	Outer mounting plate	2
46-10	R0200560-00	Bolt M8×40	4

DECKLIFT REAR ROTATING SHAFT ASSEMBLY




ITEM NO.	PART NO.	DESCRIPTION	QTY
47-01	R0201391-00	Rear height weldment	1
47-02	R0200496-00	Lock nut M8	4
47-03	R0200706-00	Inner mounting plate	2
47-04	R0200515-00	Lock nut M12	2
47-05	R0200559-00	Nut M12	2
47-06	R0200700-00	Collor	2
47-07	R0200699-00	Trunion	2
47-08	R0201392-00	Eyebolt	2
47-09	R0200707-00	Outer mounting plate	2
47-10	R0200560-00	Bolt M8×40	4
47-11	R0201394-00	Handle	1
47-12	R0200514-00	Lock nut M10	1
47-13	R0200502-00	Washer	1
47-14	R0200548-00	Washer	1
47-15	R0200531-00	Bolt M10×35	1
47-16	R0201395-00	Bushing	1
47-17	R0201397-00	Swing arm	1
47-18	R0201398-00	R-pin	1
47-19	R0200521-00	Lock nut	2
47-20	R0201399-00	Connecting rod	1
47-21	R0201402-00	Bolt M10X35	2
47-22	R0201403-00	Compression spring	1
47-23	R0201405-00	Rod	1
47-24	R0201407-00	Grip	1

WHEELS




ITEM NO.	PART NO.	DESCRIPTION	QTY
51-01	R0200889-00	Rear wheel 20x10-10	2
51-02	R0200368-00	Lug Nut 1/2-20 UNF	8
51-03	R0200711-00	Front wheel assembly 12x5-6	2
51-04	R0200360-00	Bolt M12X190	2
51-05	R0200369-00	Lock nut M12	2

FRONT CASTER PARTS




ITEM NO.	PART NO.	DESCRIPTION	QTY
52-01	R0200686-00	Dust cap	2
52-02	R0200372-00	Lock nut M20	2
52-03	R0200373-00	Disc spring	6
52-04	R0200374-00	Bearings	4
52-05	R0200375-00	Oil seal	2
52-06	R0201375-00	Caster weldment	2

DRIVE MOTOR AND TRANSMISSION




ITEM NO.	PART NO.	DESCRIPTION	QTY
55-01	R0200567-00	Bolt M8×70	8
55-02	R0200548-00	Washer	12
55-03	R0200520-00	Lock nut M8	12
55-04	R0200495-00	Bolt M10×40	2
55-05	R0200499-00	Spring washer	4
55-06	R0200502-00	Washer	4
55-07	R0200554-00	Nut M4	2
55-08	R0200536-00	Spring washer	2
55-09	R0200476-00	Neutral Lever	2
55-10	R0200500-00	Screw M4×25	2
55-11	R0200568-00	Bolt M8×60	4
55-12	R0200573-00	Support rod	1
55-13	R0200667-00	Motor Drive Assembly, 1.7 kW	2
55-14	R0200514-00	Lock nut M10	2
55-15	R0200525-00	Bolt M10×50	2
55-16	R0200474-00	Lower bracket welding	1
55-17	R0200541-00	Large washer	1

SEAT




ITEM NO.	PART NO.	DESCRIPTION	QTY
61-01	R0202165-00	Platform	1
61-02	R0200531-00	Bolt M10×35	2
61-03	R0200426-00	Bushing	2
61-04	R0200521-00	Lock nut	2
61-05	R0200682-00	Cushion	1
61-06	R0200534-00	Bolt assembly	4

CONTROL ARMS



ITEM NO.	PART NO.	DESCRIPTION	QTY
63-01	R0200679-00	Left handle	1
63-02	R0200417-00	Left steering handle weldment	1
63-03	R0200418-00	Joystick cover	1
63-04	R0200562-00	Screw M8×60	1
63-05	R0200611-00	Bushing	4
63-06	R0200366-00	Parking switch	1
63-07	R0200524-00	Screw M5×40	1
63-08	R0200600-00	Spring	1
63-09	R0200604-00	Left shaft weldment	1
63-10	R0200511-00	Nut M5	1
63-11	R0200517-00	Lock nut M5	1
63-12	R0200522-00	Lock nut M6	1
63-13	R0200676-00	Right handle	1
63-14	R0200419-00	Right handle handle weldment	1
63-15	R0200418-00	Joystick cover	1
63-16	R0200562-00	Screw M8×60	1
63-17	R0200611-00	Bushing	4
63-18	R0200366-00	Parking switch	1
63-19	R0200524-00	Screw M5×40	1
63-20	R0200600-00	Spring	1
63-21	R0200420-00	Right shaft weldment	1
63-22	R0200511-00	Nut M5	1
63-23	R0200517-00	Lock nut M5	1
63-24	R0200522-00	Lock nut M6	1


RH CONTROL ARM SUB STRUCTURE



ITEM NO.	PART NO.	DESCRIPTION	QTY
64-01	R0200675-00	Right control assembly	1
64-02	R0200614-00	Bearings	2
64-03	R0200526-00	Bolt M8×20	4
64-04	R0200456-00	Console plate	2
64-05	R0200548-00	Washer	6
64-06	R0200520-00	Lock nut M8	8
64-07	R0200398-00	Bolt M8×25	2
64-08	R0200540-00	Spring washer	1
64-09	R0200541-00	Large washer	2
64-10	R0200389-00	Spacer collar	2
64-11	R0200434-00	Spring hanging plate	2
64-12	R0200585-00	Sleeve	1
64-13	R0200388-00	Nylon washer	1
64-14	R0200356-00	Return spring	1
64-15	R0200415-00	Right rotating plate	1
64-16	R0200490-00	Linkage	1
64-17	R0200381-00	Rod end M6	1
64-18	R0200382-00	Nut M6	1
64-19	R0200475-00	Adjustment screw	1
64-20	R0200383-00	Nut (reverse) M6	1
64-21	R0200361-00	Rod end(reverse) M6	1
64-22	R0200532-00	Bolt assembly	3
64-23	R0200435-00	Limit plate	1
64-24	R0200599-00	Shaft weldment	1
64-25	R0200564-00	Screw M6X6	1
64-26	R0200518-00	Lock nut M6	3
64-27	R0200491-00	Return link	1
64-28	R0200387-00	Rod end M8	1
64-29	R0200519-00	Nut M8	1
64-30	R0200477-00	Return rod	1
64-31	R0200563-00	Nut M8	1
64-32	R0200394-00	Rod end M8	1
64-33	R0200507-00	Bolt M6×20	3
64-34	R0200416-00	Right fixed plate weldment	1

ITEM NO.	PART NO.	DESCRIPTION	QTY
64-35	R0200565-00	Screw ST4.2×10	2
64-36	R0200433-00	Sensor connection plate AC	1
64-37	R0200354-00	Accelerator sensor	1
64-38	R0200527-00	Bolt M8×25	2
64-39	R0201097-00	Spacer	1
64-40	R0201098-00	Damper	1
64-41	R0200522-00	Nut M6	1
64-42	R0200496-00	Lock nut M8	1

LH CONTROL ARM SUB STRUCTURE



ITEM NO.	PART NO.	DESCRIPTION	QTY
65-01	R0200678-00	Left control assembly	1
65-02	R0200614-00	Bearings	2
65-03	R0200526-00	Bolt M8×20	4
65-04	R0200456-00	Console plate	2
65-05	R0200548-00	Washer	6
65-06	R0200520-00	Lock nut M8	8
65-07	R0200398-00	Bolt M8×25	2
65-08	R0200540-00	Spring washer	1
65-09	R0200541-00	Large washer	2
65-10	R0200389-00	Spacer collar	2
65-11	R0200434-00	Spring hanging plate	2
65-12	R0200585-00	Sleeve	1
65-13	R0200388-00	Nylon washer	1
65-14	R0200356-00	Return spring	1
65-15	R0200436-00	Left rotating plate	1
65-16	R0200490-00	Linkage	1
65-17	R0200381-00	Rod end M6	1
65-18	R0200382-00	Nut M6	1
65-19	R0200475-00	Adjustment screw	1
65-20	R0200383-00	Nut M6 (reverse)	1
65-21	R0200361-00	Rod end M6 (reverse)	1
65-22	R0200532-00	Bolt assembly	3
65-23	R0200435-00	Limit plate	1
65-24	R0200599-00	Shaft weldment	1
65-25	R0200564-00	Screw M6×6	1
65-26	R0200518-00	Lock nut M6	3
65-27	R0200491-00	Return link	1
65-28	R0200387-00	Rod end M8	1
65-29	R0200519-00	Nut M8	1
65-30	R0200477-00	Return rod	1
65-31	R0200563-00	Nut M8	1
65-32	R0200394-00	Rod end M8	1
65-33	R0200507-00	Bolt M6×20	3

ITEM NO.	PART NO.	DESCRIPTION	QTY
65-34	R0200594-00	Left fixed plate weldment	1
65-35	R0200565-00	Screw ST4.2×10	2
65-36	R0200433-00	Sensor connection plate AC	1
65-37	R0200354-00	Accelerator sensor	1
65-38	R0200527-00	Bolt M8×25	2
65-39	R0201097-00	Spacer	1
65-40	R0201098-00	Damper	1
65-41	R0200522-00	Nut M6	1
65-42	R0200496-00	Lock nut M8	1

GREENWORKS

COMMERCIAL

**Greenworks Tools
PO Box 1238
 Mooresville, NC 28115**

TOLL-FREE HELPLINE: 1-855-470-4267