

# Good Practice Guide

## Glass and Dishwashing

UK

### Getting The Best From Your Machine

#### DO

- ✓ DO allow the machine to heat for at least 45 minutes or until the green light is on.
- ✓ DO check detergent and rinse aid levels in bottles.
- ✓ DO pre-rinse all glasses, cutlery and crockery.
- ✓ DO ensure all filters are in position.
- ✓ DO allow machine to complete full wash cycle.
- ✓ DO ensure water softener (if fitted) is regenerated with salt regularly\*.

#### DO NOT

- ✗ DO NOT switch the machine OFF whilst washing/rinsing.
- ✗ DO NOT open machine hood whilst washing/rinsing.
- ✗ DO NOT overload basket.
- ✗ DO NOT wash ash trays.

### Keeping Your Machine Clean

#### DO

- ✓ DO change the wash water regularly.
- ✓ DO remove wash and rinse arms daily and clean.
- ✓ DO remove basket ramp daily and clean.
- ✓ DO remove all filters daily and clean.
- ✓ DO wash the chamber out daily.
- ✓ DO leave the hood open after cleaning.

#### DO NOT

- ✗ DO NOT use domestic detergents.
- ✗ DO NOT use cleaning agents that contain Chlorine, Bleach or Hypochlorite.
- ✗ DO NOT use steel wool, wire brushes or any other abrasive materials.
- ✗ DO NOT use a jet wash or hose pipe on the machine.

\*Damage caused to the machine by limescale damage due to lack of water softener or incorrect regeneration of a softener is **NEVER** covered by the manufacturers warranty.

# CLASSEQ