



# VEGGIE STEAMER

## HOW TO USE YOUR VEGGIE STEAMER:

**Optional:** Add salt, pepper and seasonings to taste.

1. Add 1-2 tablespoons of water to the steamer.
2. Add in chopped vegetables of choice and cover with lid.
3. Microwave on high for 2-4 minutes, depending on how well you want your veggies.

Microwave use only. Do not use on stovetop.

**DISHWASHER SAFE**