



Optional: coat with butter or cooking spray. Add salt, pepper, butter to taste.

Scrambled: crack one egg in maker, beat and microwave on high for 45-50 seconds.

Fried: crack one egg in maker, poke hole in yolk and microwave high for 45 seconds.

Sunny Side Up: crack one egg in maker leaving yolk intact, microwave on high for 20 seconds then stop, another 15 seconds then stop, last 10 seconds and done!

Cooking times may vary by microwave

Microwave use only, do not use on stovetop

Dishwasher safe