

# OWNER'S MANUAL

# CAMBRO® KD UTILITY CARTS

This manual applies to the following Cambro products:

KD UTILITY CARTS - BC340KD, BC340KDLP

Congratulations on the purchase of your Cambro® KD Utility Cart. This Owner's Manual provides you a step-by-step assembly guide. If you have further questions, please contact us, visit [www.cambro.com](http://www.cambro.com) or call our Customer Service Department.

Para español, por favor visite el portal de Cambro en [www.cambro.com](http://www.cambro.com)  
 Pour la version française, veuillez consulter le site Web de Cambro [www.cambro.com](http://www.cambro.com)  
 Per la versione italiana consultate il sito di Cambro: [www.cambro.com](http://www.cambro.com)  
 Für Deutsch besuchen Sie bitte die Cambro Website [www.cambro.com](http://www.cambro.com)  
 Ga voor Nederlands naar de Cambro website [www.cambro.com](http://www.cambro.com)  
 Informacje po polsku znajdują się na stronie [www.cambro.com](http://www.cambro.com)  
 Материалы на русском языке см. на сайте фирмы Cambro по адресу [www.cambro.com](http://www.cambro.com)

## PARTS- Build from the bottom shelf up

1. Handle - 2 each
2. Top Shelf - 1 each
3. Handle Screws - 4 each
4. Rear Enclosure Panel - 2 each - Assembly Optional* (Model BC340KDLP not applicable)
5. Side Enclosure Panel - 4 each - Assembly Optional* (Model BC340KDLP not applicable)
6. Aluminum Support Post - 8 each
7. Middle Shelf - 1 each
8. Bottom Shelf - 1 each
9. 5" (12.7 cm) Swivel Caster - 4 each (Model BC340KDLP includes brakes)
10. Cap - 2 each - Assembly Optional

## DIRECTIONS- Prior to assembly:

Check under each shelf to identify top, middle and bottom.

Begin assembly with bottom shelf.

Ensure higher side ledges of shelves are in same direction on cart.

**USE RUBBER Mallet ONLY. DO NOT USE METAL HAMMER.**

- Place one shelf support on each corner locator of bottom shelf.  
**NOTE:** Match grooves in shelf support to grooves in shelf corner locators.
- Use mallet to tap each corner down until there are no gaps between supports and shelf corner locators.
- If adding panels, slide one panel at a time onto grooves, starting with back panel first. Then add middle shelf.
- Place a shelf support onto each corner locator and tap down.
- Repeat number 3 and then 4 if adding one more panel set.
- Attach handles to top shelf before placing onto cart. Secure with screws through bottom hole of shelf under each handle end. Then tap top shelf into place.  
**NOTE:** When using 1 handle instead of 2, please see diagram above for part #10.
- Add casters and tap securely into place.

